

PINCE NEZ GUIDE by SALT

Folding 1840-



Unsprung



Sprung



Double sprung

C Spring
1880-1940



Japanese



Canadian



Perfection



Rimless "Fairy"



American Oxford

Astig 1890-1940
(allowed use of cylinder)



Rigid bar



Canadian pads

"Ocentric" type 1910-1950
(British made)



Rimless

Fingerpiece 1900-1940



Rimless